

## Mains Power Supply Warnings and Instructions (ACS-0005, ACS-0041 & ACS-0044)

### Warnings

- For indoor use only
- Do not dismantle; no user serviceable parts
- Inspect before each use and discard if damaged
- Use only the adaptors supplied
- Do not insert the adaptors in a wall socket without the body of the supply attached
- For use with Tinytag Products only

### Instructions

- The power supply will operate with inputs between 100V and 240V at 50Hz or 60Hz.
- The power supply is only suitable for use at altitudes below 2000m.

#### ACS-0005 & ACS-0044

- The power supply is supplied with adaptors for UK (BS 1363), EU (CEE 7/16) and US (NEMA 1-15P) sockets. It must only be used with compatible sockets.
- To fit a plug adaptor, hook the plastic tab on the adaptor into the recess on the body of the power supply, click into place. Ensure that the adaptor is secure before use.
- To remove the plug adaptor, slide the locking tab in the direction of the arrow and unclip the adaptor.

#### ACS-0041

- The injector is supplied with adaptors for UK (BS 1363), EU (CEE 7/16), US (NEMA 1-15P) and AUS (AS/NZS 3112) sockets. It must only be used with compatible sockets.
- To fit a plug adaptor, slide it into the body of the injector until it clicks in place. Ensure that the adaptor is secure before use.
- To remove the plug adaptor, press the "Push" tab and slide the adaptor out of the injector.

### Warranty

This power supply/injector is supplied with a one year warranty for manufacturing and design defects.

### Approvals

Gemini Data Loggers (UK) Ltd. operates a Business Management System which conforms to ISO 9001 and ISO 14001.

### Supplied By

**Gemini Data Loggers (UK) Ltd.**  
Scientific House  
Terminus Road  
Chichester  
West Sussex  
PO19 8uJ  
England

t: +44 (0)1243 813000  
e: sales@tinytag.info  
w: www.tinytag.info

## Mains Power Supply Warnings and Instructions (ACS-0005, ACS-0041 & ACS-0044)

### Warnings

- For indoor use only
- Do not dismantle; no user serviceable parts
- Inspect before each use and discard if damaged
- Use only the adaptors supplied
- Do not insert the adaptors in a wall socket without the body of the supply attached
- For use with Tinytag Products only

### Instructions

- The power supply will operate with inputs between 100V and 240V at 50Hz or 60Hz.
- The power supply is only suitable for use at altitudes below 2000m.

#### ACS-0005 & ACS-0044

- The power supply is supplied with adaptors for UK (BS 1363), EU (CEE 7/16) and US (NEMA 1-15P) sockets. It must only be used with compatible sockets.
- To fit a plug adaptor, hook the plastic tab on the adaptor into the recess on the body of the power supply, click into place. Ensure that the adaptor is secure before use.
- To remove the plug adaptor, slide the locking tab in the direction of the arrow and unclip the adaptor.

#### ACS-0041

- The injector is supplied with adaptors for UK (BS 1363), EU (CEE 7/16), US (NEMA 1-15P) and AUS (AS/NZS 3112) sockets. It must only be used with compatible sockets.
- To fit a plug adaptor, slide in into the body of the injector until it clicks in place. Ensure that the adaptor is secure before use.
- To remove the plug adaptor, press the "Push" tab and slide the adaptor out of the injector.

### Warranty

This power supply/injector is supplied with a one year warranty for manufacturing and design defects.

### Approvals

Gemini Data Loggers (UK) Ltd. operates a Business Management System which conforms to ISO 9001 and ISO 14001.

### Supplied By

**Gemini Data Loggers (UK) Ltd.**  
Scientific House  
Terminus Road  
Chichester  
West Sussex  
PO19 8uJ  
England

t: +44 (0)1243 813000  
e: sales@tinytag.info  
w: www.tinytag.info